


INSTRUCTION MANUAL


Model: Magni Charge Superflex Gulvlampe

Installation




- ① Install lamp head part to middle pole. Insert power cord into middle pole, gently pull the excess power cord out through the middle pole so that it does not get caught in the threading.
Monter lampehovedets del på midterstolpen. Sæt strømkablet i midterstolpen, Træk forsigtigt overskydende strømkabel ud gennem den midterste stang, så det gør ikke blive fanget i tråden.
- ② Repeat last step to install bottom pole to middle pole.
Gentag sidste trin for at installere bundstang til midterste stang
- ③ Connect the wiring terminals, Rotate bottom pole counterclockwise and install bottom pole to lamp base.
Tilslut ledningsterminalerne, drej bundpolen mod uret og installer bundpolen til lampebasen.
- ④ Connect power supply adaptor, plug into charging port, then the lamp is ready for using. The lamp is rechargeable.
Tilslut strømforsyningsadapter, stik ind i ladeporten, så er lampen klar til brug. Lygten er genopladelig

Product description / Produktbeskrivelse




- ① Lamp head lid: To cover the magnifier to avoid the sun from setting fire.
Lampehovedlåg: Til at dække forstørrelsesglas for at undgå, at solen sætter ild.
- ② Rotating switch: Pressing for turning on/off, Rotating for dimming brightness
Drejelig kontakt: Tryk for at tænde/slukke, Drej for at dæmpe lysstyrken
- ③ Rotating shaft: Lamp head can be rotated 300° vertically to the neck
Roterende aksel: Lampehovedet kan rangeres 300° lodret til halsen
- ④ Touching Switch: Touch to dim light color temperature 5 grades of color temperatures
Touching Switch: Tryk på for at dæmpe lysfarvetemperatur 5 grader af farve temperaturer
- ⑤ DC charging port: Plug into DC plug of adaptor to use lamp or to charge the lamp.
DC-opladningsport: Tilslut DC-adapterens stik for at bruge lampen eller oplade lampen.

Attention / Opmærksomhed



Avoid causing the rotating switch to fall off, please do not pull it.
Undgå at forårsage den roterende kontakt for at falde af, må du ikke trække den.



Avoid damaging the hose, please do not bend the hose excessively when adjust lighting angle.
Undgå at beskadige slangen, bøj ikke slangen for meget, når lysvinklen justeres.



The lamp is for indoor use, but can be brought outside in "battery mode".
The lamp is not waterproof or suitable for use in humid surroundings.
Lampen er til indendørs brug, men kan bringes udenfor i "batteritilstand".
Lampen er ikke vandtæt eller egnet til brug i fugtige omgivelser.

**halo
design**

COPENHAGEN